



DOOR FACE TEMPLATE (LEFT)

DOOR EDGE TEMPLATE

DOOR FACE TEMPLATE (RIGHT)

IMPORTANT NOTES:

- Remove lockset from mortice hole before drilling any holes.
- Do not drill holes right through door from one side only – potential misalignment.
- Mortice hole to be clean and free of any loose material.

