




PAIT 070



Jainsborou



FOLD HERE



## Fit here on door edge

## TRILOCK DUMMY FITTING INSTRUCTIONS

- Fold template where indicated.
  - Position template on door edge at desired height.(Generally to line up with operating Trilock on opposite door)
- Firmly hold template to door and mark the four hole centres as indicated.
- Drill holes (suggest pilot holes first
- 3mm, 1/8") then the correct size 10mm, 3/8" from both sides of the
- door.

## **Contemporary Series**

- Install threaded posts to the outside faceplate.
- **Traditional Series**
- Install blind screws and brass posts to Trilock external faceplate (this is the faceplate without the rectangle snib push-button).
- Insert dummy plug into the inside of both plates before affixing faceplates to door. (To help hold dummy plugs in position, apply a strip of adhesive tape if required.)
- Mount the outside faceplate to door.
- Align the inside faceplate to door and fit mounting screws and tighten into threaded posts.

– 10mm – (3/8") hole



PAIT 070 JUL '11