







GUIDES



40C/19 PIGGYBACK
BOTTOM GUIDE
- FITS 19 CHANNEL



40x25 BOTTOM GUIDE
- FITS 25 CHANNEL
FOR TIMBER DOORS

